EDISON PENDANT

BAREBONES

USERS GUIDE

ON/OFF

Plug your light into a USB power source. Switch power to LOW or HIGH.

CHAINING & HANGING

Connect up to nine individual Edison Pendant lights using the integrated USBs. Connecting more will cause the lights to dim. When operating chained lights, the switch closest to the power source will regulate the entire line; other switches in chain should be set to high.

POWER AND BRIGHTNESS

3-level switch.

For low light: push the switch to the LOW indicator. For brighter light: push the switch to the HIGH indicator. To turn off: flip the switch back to the center. For best results, use a USB power source with a 5V output.

TECHNICAL SPECIFICATIONS 1.6W warm white LED LED: Light color 3000 Kelvin Low: 35 / High: 100 5V USB A Lumen Power supply:

Carabiner for hanging Steel

MAINTENANCE

It is unnecessary to disassemble the upper LED housing of your lights. Doing so may damage the light and void the warranty. Please clean your lights periodically. If needed wipe the base with damp cloth. Do not disassemble the lantern. This may damage the lantern and void the warranty.

SAFTEY INSTRUCTION

- This product is not intended for use by children.
- Do not look directly into the light.

ENVIRONMENTALLY FRIENDLY WASTE DISPOSAL

Recycling - European Directive 2012-19/EU. This marking indicates that this product must not be disposed of with other household waste. In order not to endanger the environment and human health and to promote the recycling of resources, this product must be disposed of responsibly. Please hand in the used product at the designated collection points for electronic waste.

COMPLIANCE AND CERTIFICATES















Barebones Living LCC provides a 2-year warranty on all defects resulting from hidden faults and which make the product unsuitable for normal use. The warranty takes effect at the time of purchase; please keep the receipt carefully.

For more information, please see: www.barebonesliving.eu or email: service@barebonesliving.eu

