ENAMEL

BAREBONES

CARE

Fit for all heat sources, apart from microwave and oven (when featured with FSG walnut accents).

Our enamelware rim is heat-treated to create a bronze-like patina finish. Both the plate surface and rim can be stripped of its unique coloring by acidic foods, such as lemon, and some harsh detergents and cleansers. Enamelware is dishwasher safe, but we recommend hand washing to help maintain the original look and feel of the pieces.

Hand wash only. Do not microwave.To hand wash: Use a gentle, natural cleanser. Soak the products in warm, soapy water to help remove baked-on food. Gently wipe away residue. Avoid using abrasive sponges or brushes as this may scratch the surface.

Barebones Living LCC provides a 2-year warranty on all defects resulting from hidden faults and which make the product unsuitable for normal use. The warranty takes effect at the time of purchase; please keep the receipt carefully.

For more information, please see: www.barebonesliving.eu or email: service@barebonesliving.eu