


BAREBONES


Block
TOWER



BLOCK TOWER LANTERN

Quick Start Guide


WHAT'S IN THE BOX?



For optimal battery lifespan and performance, fully charge before first use and at least once every 3 months.

CONTROLS

Top View




CANDLE FLICKER MODE

Starting from the OFF position, quickly turn the lantern ON and OFF 3 times. Turn the lantern ON a 4th time to access Candle Flicker Mode.


Note: Brightness is still adjustable in Candle Flicker Mode.

POWER LEVEL




● ● ● ●	75% - 100%
● ● ● ○	50% - 74%
● ● ○ ○	25% - 49%
● ○ ○ ○	Less than 24%

WIRELESS CHARGING OPTIONS



The lantern is capable of charging wirelessly via the disc located on its base.




Option 1

BLOCK TOWER POWER STATION

The lantern stacks perfectly on top of the Block Tower Power Station to charge wirelessly.

WIRELESS CHARGING OPTIONS




Option 2

WIRELESS CHARGING PAD

Place the lantern base on the center of the wireless charger. When the lantern is aligned properly with the charger, the amber LED lights will begin to blink indicating the battery level.

WIRED CHARGING




WARNINGS & SAFETY

- Do not attempt to disassemble the lantern.
- Keep away from extreme heat, direct sunlight, or fire.
- Avoid exposure to rain, moisture, or extreme weather conditions.
- Handle with care to prevent scratches, dents, or damage to the brass faceplate and housing.
- Do not use abrasive cleaners or solvents that may harm the surface.
- Avoid placing the lantern on uneven surfaces or near edges where it may fall.
- Keep away from children to prevent choking hazards.
- To prevent eye damage, avoid staring directly at the LED light.
- Regularly inspect the lantern for any signs of wear, damage, or unusual behavior. In case of any malfunction or if the lantern becomes unusually hot, power it off immediately and contact customer support for assistance.

Follow these guidelines to ensure the safe and proper use of your lantern. Failure to adhere to these warnings may result in damage to the device, injury, or other safety hazards.

SPECIFICATIONS



LED	12V FILAMENT 600X LOW: 0.1W HIGH: 8W
-----	--

LUMENS	LOW: 3 HIGH: 500
--------	--------------------

TEMPERATURE	2700K
-------------	-------

BATTERY	LI-ION 18650 3.7V. 2600MAH, 9.62WH
---------	--------------------------------------

RUN TIME	LOW: 100+ HOURS HIGH: 2~3 HOURS
----------	-----------------------------------

CHARGE TIME	3-4 HOURS
-------------	-----------

WIRELESS (Input)	5W
------------------	----

USB-C (Input)	5V-1A; 5W MAX
---------------	---------------

DIMENSIONS	4" x 4" x 4.5" (7" handle up) 1.15 lbs
------------	--



CEC RoHS



BAREBONES

Block
TOWER



SCAN FOR THE FULL GUIDE

Includes:

- Battery Replacement
- Specifications
- Care

BAREBONESLIVING.COM

DESIGNED IN UTAH | MADE IN CHINA



Certified



Corporation

