

FOREST LANTERN

Battery Replacement

BAREBONES

PRODUCT COMPONENTS





REMOVING THE BATTERY

 Place Forest Lantern A on side so the base of the lantern is accessible.

Note: Place lantern on a clean, soft surface to prevent scratching.

- 2. Using a Phillips-head screwdriver, remove the screws B from the battery cover C.
- 3. Remove the battery cover C.
- 4. Remove the Li-ion battery D.

REPLACING THE BATTERY

- Insert the Barebones specific Li-ion battery into place with the exposed metal connecting to coils.
 - Note: Do not remove battery wrap. Doing so will ruin the battery.
- Test the battery connection by turning on the Forest Lantern A.
- 3. Place the battery cover (a) into position.
- Secure battery cover (C) with screws (B).

 Note: Do not overtighten. Overtightening can
 damage the battery plate or strip the screws.

BAREBONES

Customer Service 1-855-895-7040

Email info@barebonesliving.com

080221

Scan the QR code to view this information online.



BAREBONESLIVING.COM/INSTRUCTIONS