




FOREST LANTERN

User Guide

BAREBONES

KEY PRODUCT FEATURES



OPERATING INSTRUCTIONS

Test Mode

The Forest Lantern comes set in Test Mode. While in Test Mode, the lantern will turn on for 10 seconds before automatically turning off.

Note: *The lantern cannot be manually turned off during the 10 second demonstration.*

Functional Mode

To switch to Functional Mode, press and hold the Power Switch **C** for 10 seconds. The Battery Life Indicator **D** will flash 4 times confirming the mode has switched. You can also simply charge the lantern to switch to functional mode.

On/Off

Press the Power Switch **C** once to turn the Forest Lantern on. Press it a second time to turn it off.

Adjusting Brightness

Turn the Dimmer Switch **C** clockwise to increase brightness and counter-clockwise to decrease brightness.

How often should I recharge the light?

To prolong the life of the Lithium Ion batteries, it's important to keep your light charged. Your light needs to be charged every six months, even if its not in regular use.

Why is my battery life indicator?

The Battery Life Indicator  will begin blinking when it's time to charge your lantern.

Will I need to replace the LED?

Your Forest Lantern was designed to not require LED replacement. It comes with a one year warranty and is rated for 20,000 hours of use.

SPECIFICATIONS



LED	5 WATT CREE
LIGHT SPECTRUM	3000 KELVIN
BATTERY	(2) 8W LITHIUM-ION CELL
RECHARGE TIME	4-6 HOURS
RUN TIME	LOW: 80+ HRS HIGH: UP TO 4 HRS
INPUT	5V, UP TO 1A MAX
DIMENSIONS	6" x 9.5"(12.5" w/ HANDLE) x 6"



RoHS



BAREBONES

Customer Service

1-855-895-7040

Email

info@barebonesliving.com

080221

Scan the QR code to view this information online.



BAREBONESLIVING.COM/INSTRUCTIONS